

TWINLIGHT

24 Shanahan pde.
Redbank Plains, Qld.
Ph.: 07 3814 4078
Mobile: 0417 190 638
Fax: 07 3814 5768
Email: sven@twinlight.com.au

Instructions for fitting headlights to XF / XG

- 1: Remove front covers and paint.
- 2: Fit lense to painted cover and hold in place with masking tape
- 3: Run a bead of clear or black Silicone or black Sikaflex around retaining edge on back of lense
- 4: Reassemble lights after everything has set and fit to car
- 5: Aim headlights on level ground, 3 meters away from wall, center of light beam should be same height as center of lights



!WARNING! - If the headlights go off on high beam, the fusible link mounted on the end of the relay block next to the battery may need replacing with Narva 40amp circuit breaker, Narva part no 54740BL

(Headlights assembly should be removed from car prior to removing front covers)

